

EN TECHNOLOGY®
DURO

*Voor meer tijd
op vakantie!*



Enduro EM505FL en EM515FL werking In combinatie met AutoSteady AS201




EN TECHNOLOGY®
DURO

JOUW SPECIALIST OP HET GEBIED VAN RANGEERSYSTEMEN EN ACCESSOIRES
WWW.ENDURO-EUROPE.EU

Aankomst vakantie plek

1 Rangeer de caravan naar de plek waar je deze wilt hebben.

2 Leg aan de kant welke hogerop moet komen een wielkeg achter het wiel.



3 Draai het neuswiel iets, totdat het 1ste bolletje boven het waterpas oplicht.

4 Druk op de FL toets tot deze geactiveerd is. De FL-functie start alleen wanneer de caravan binnen een 'compenseerbaar' bereik waterpas is te stellen (hoogte verschil over de as <math>< 10\text{cm}</math>) en de neus van de caravan in aanvang iets onder waterpas neigt.

Staat de caravan buiten het compenseerbare bereik dat blijft de FL-indicatie knipperen.

5 Rangeer de caravan achterwaarts de wielkeg op (voorkeur). De caravan stopt automatisch als deze in de breedte waterpas is. Na een paar seconden gaan eerst de voorsteunen naar beneden tot de caravan in de lengte bijna recht staat. Na een paar seconden gaan de achtersteunen naar beneden. Hierna volgt voor alle vier de steunen gelijktijdig een korte boost. Nu staat de caravan waterpas.

6 Zet de caravan goed op de handrem!



7 Haal nu de aandrijfrollen van de wielen.

8 Schakel alles uit (hoofdschakelaar en afstandsbediening).

Vertrek vakantie plek

- 1 Schakel het systeem en de handzender in.
- 2 De FL-indicator licht op als teken dat deze nog actief is.
- 3 Druk de FL toets in. Na een paar seconden zet het systeem automatisch de aandrijfrollen op de wielen.
- 4 Na een paar seconden worden automatisch de uitdraaisteunen ingetrokken.
- 5 Haal de caravan van de handrem.
- 6 Rangeer de caravan voorzichtig van de wielkeg.
- 7 Schakel het systeem en de handzender uit.



Handmatig na stellen

1 Schakel het systeem en de handzender in.



2 Selecteer de uitdraasteunen functie.



3 Druk op de pijl omhoog of omlaag om de beweegricting van de steunen te selecteren. De handzender geeft de geselecteerde beweegricting aan.



4 Nu kun je alle vier de uitdraasteunen individueel bewegen.



EN TECHNOLOGY®
DURO

*For more time
on vacation*



Operating Enduro EM505FL and EM515FL In combination with AutoSteady AS201




EN TECHNOLOGY®
DURO

YOUR SPECIALIST FOR MANOEUVRING SYSTEMS AND ACCESSORIES
WWW.ENDURO-EUROPE.EU

Arrival vacation spot

- 1 Manoeuvre the caravan to the place where you want it.
- 2 Place a wheel chock behind the wheel on the side that needs to be higher up.
- 3 Turn the nose wheel slightly until the 1st ball lights up above the level.



- 4 Press the FL button until it is activated.

The FL function only starts when the caravan can be leveled within a 'compensable' range (height difference over the axle <math><10\text{cm}</math>) and the nose of the caravan is slightly below the level.

If the caravan is outside the compensable range, the FL indicator will continue to flash.

- 5 Manoeuvre the caravan backwards onto the wheel chock (preferably). The caravan stops automatically when it is horizontally level. After a few seconds, the front supports will go down first until the caravan is almost straight lengthwise. After a few seconds, the rear supports go down. Followed by a short boost simultaneously to all four supports. The caravan is now level.

- 6 Put the caravan firmly on the handbrake!



- 7 Remove now the drive rollers from the wheels.

- 8 Switch everything off (main switch and remote control).

Departure vacation spot

- 1 Switch everything on (main switch and remote control).
- 2 The FL indicator lights up to indicate that it is active.
- 3 Press the FL key. After a few seconds, the system automatically puts the drive rollers on the wheels.
- 4 After a few seconds, the corner steadies withdraw automatically.
- 5 Release the caravan from the handbrake.
- 6 Manoeuvre the caravan carefully off the wheel chock.
- 7 Switch everything off (main switch and remote control).



Adjust manually

1 Switch everything on (main switch and remote control).



2 Select the corner steadies function.



3 Press the up or down arrow to select the direction of movement of the supports. The remote control indicates the selected direction of movement.



4 Now you can move all four corner steadies individually.

